



NOTE: USE PVC PRIMER AND  
GLUE ON ALL SOCKET JOINTS  
AND TEFLON TAPE ON ALL  
THREADS

DRAWING: AIR CANNON	SOUTHEAST POLYTECH DEPT.	COURSE/SECTION: MN120-01
DRAWN BY: TEAM 3	SCALE: 1 : 8	SHEET: 3 OF 8      DATE: 5/11/2017