



NOTE: PLACE PLATFORMS ON TOP OF EACH OTHER AND PRE-DRILL ALL SCREW HOLES FOR HINGES AND SUPPORT BLOCKS USING A  $\frac{1}{16}$ " DRILL BIT.

|                  |                          |                               |
|------------------|--------------------------|-------------------------------|
| DRAWING: BASE    | SOUTHEAST POLYTECH DEPT. | COURSE/SECTION: MN120-01      |
| DRAWN BY: TEAM 3 | SCALE: 1 : 4             | SHEET: 2 OF 8 DATE: 5/11/2017 |